

QUICK AND EASY

- Complete attic coverage in as little as 2 hours*
- Self-feeding system
- Puts FIBERGLAS® insulation where you want it
- Integrated AUTOCUTTER

SAFE AND RELIABLE SYSTEM

- Optimized process for minimal handling
- Fully enclosed blowing system
- Hose-mounted remote control

VIRTUALLY NO MESS


- FIBERGLAS® insulation releases and expands completely inside machine
- Provides easy cleanup (machine does the work)
- Low-dust system

VIRTUALLY NO SETTLING

- Over time, there's virtually no settling of AttiCat®
- Heating and cooling saving* R-value

GET YEAR-ROUND COMFORT WITH PINK®

- ✓ Highest recycled content in the industry*, SCS certified
- ✓ GREENGUARD Gold Certified and validated to be formaldehyde-free



Topping up your attic can **save up to 20%** on heating and cooling costs*. Use the AttiCat® Expanding Blown-In Insulation System and the job is done in as little as 2 hours*!

"This is one of the best insulation blowing machines available that I have used that doesn't cost what the larger professional machines do. You also don't need a large truck or trailer to tow it around on."

Mitch



"Worked great insulating our house we just purchased. Old home with very little insulation so we used AttiCat® Insulation and it was very easy and worked great!"

Janine



To learn more about Owens Corning® products, visit [owenscorning.ca](https://www.owenscorning.ca)



Subscribe to the **Owens Corning Canada's YouTube channel** for helpful how-to videos.



Follow us on Facebook at facebook.com/owenscorningcanada




Pub. No. 500860F. Printed in Canada. August 2024. THE PINK PANTHER™ & © 1964-2024 Metro-Goldwyn-Mayer Studios Inc. All Rights Reserved. The colour PINK is a registered trademark of Owens Corning. © 2024 Owens Corning. *Heating and cooling costs only. Up to 20% savings based on Hot 2000, Version 8.7 run for a 2-storey 1972 type base house with 1,149 sq. ft. per floor for an increase from R-8 to R-40 in the attic in Canadian climates. Savings vary depending on original amount of insulation in your home, climate, house size, air leaks, and personal energy use and living habits. *Total recycled content for unfaced fiberglass insulation products in North America based on current third-party certified recycled content certifications for Owens Corning, Knauf, CertainTeed and Johns Manville. Validated by Owens Corning Sustainability, September 2023. Blowing time, based on attic size 100m²/1,000ft² at RSI 8.8/R-50. **Comparison based on 1,000 sq. ft. coverage of AttiCat® Blown-In Insulation (R-20) as compared to blown insulation (R-20) of a leading manufacturer of cellulose insulation. See CCMC Evaluation Report No. 12851-L.



ATTICAT®
PINK®
BLOWN-IN INSULATION

SAVE ON YOUR HEATING AND COOLING BILLS IN AS LITTLE AS 2 HOURS.



HOW MANY BAGS OF INSULATION ARE REQUIRED?

Refer to the chart below to determine the amount of AttiCat® Insulation you need in your attic. To achieve maximum energy efficiency, an R-value of 80 is recommended for most Canadian attics (for more information, check local building codes).



1 BAG
ATTICAT®
INSULATION

=



3 BAGS
CELLULOSE™
INSULATION

✓ Fewer bags required!

✓ Compact for easy transport and install

ATTICAT® MACHINE AND PRODUCT PICK-UP

Grab your bags of AttiCat® Expanding Blown-In PINK® FIBERGLAS® Insulation and AttiCat® rulers, and head over to the machine rental department to pick up the AttiCat® machine. There, you will receive

OWENS CORNING® RECOMMENDS R-80 – ALL YOU NEED IS 28-1/2"

R-VALUE	R-12	R-16	R-20	R-24	R-28	R-32	R-36	R-40	R-44	R-48	R-50	R-52	R-56	R-60	R-64	R-68	R-70	R-72	R-76	R-80
BLOWN INCHES	4.5	6.0	7.4	8.9	10.4	11.9	13.3	14.6	16.0	17.4	18.0	18.8	20.1	21.5	22.9	24.2	24.9	25.6	26.9	28.5
COVERAGE/BAG (FT²)	162.0	121.5	97.2	81.0	69.4	60.7	53.2	47.4	42.6	38.8	37.2	35.5	32.9	30.5	28.5	26.7	25.9	25.1	23.7	22.3
NUMBER OF 30 LB./13.6KG ATTICAT® BAGS REQUIRED																				
SQ. FT.	R-12	R-16	R-20	R-24	R-28	R-32	R-36	R-40	R-44	R-48	R-50	R-52	R-56	R-60	R-64	R-68	R-70	R-72	R-76	R-80
500	3.1	4.1	5.1	6.2	7.2	8.2	9.4	10.6	11.7	12.9	13.4	14.1	15.2	16.4	17.6	18.7	19.3	19.9	21.1	22.4
600	3.7	4.9	6.2	7.4	8.6	9.9	11.3	12.7	14.1	15.5	16.1	16.9	18.3	19.7	21.1	22.5	23.2	23.9	25.3	26.9
700	4.3	5.8	7.2	8.6	10.1	11.5	13.2	14.8	16.4	18.1	18.8	19.7	21.3	22.9	24.6	26.2	27.0	27.9	29.5	31.4
800	4.9	6.6	8.2	9.9	11.5	13.2	15.0	16.9	18.8	20.6	21.5	22.5	24.3	26.2	28.1	30.0	30.9	31.9	33.7	35.9
900	5.6	7.4	9.3	11.1	13.0	14.8	16.9	19.0	21.1	23.2	24.2	25.3	27.4	29.5	31.6	33.7	34.7	35.8	37.9	40.4
1,000	6.2	8.2	10.3	12.3	14.4	16.5	18.8	21.1	23.4	25.8	26.9	28.1	30.4	32.8	35.1	37.4	38.6	39.8	42.1	44.8
1,100	6.8	9.1	11.3	13.6	15.8	18.1	20.7	23.2	25.8	28.4	29.5	31.0	33.5	36.1	38.7	41.2	42.5	43.8	46.3	49.3
1,200	7.4	9.9	12.3	14.8	17.3	19.8	22.6	25.3	28.1	30.9	32.2	33.8	36.5	39.3	42.2	44.9	46.3	47.8	50.5	53.8
1,300	8.0	10.7	13.4	16.0	18.7	21.4	24.4	27.5	30.5	33.5	34.9	36.6	39.6	42.6	45.7	48.7	50.2	51.8	54.8	58.3
1,400	8.6	11.5	14.4	17.3	20.2	23.1	26.3	29.6	32.8	36.1	37.6	39.4	42.6	45.9	49.2	52.4	54.0	55.7	59.0	62.8
1,500	9.3	12.3	15.4	18.5	21.6	24.7	28.2	31.7	35.2	38.7	40.3	42.2	45.6	49.2	52.7	56.2	57.9	59.7	63.2	67.3
1,600	9.9	13.2	16.5	19.8	23.0	26.4	30.1	33.8	37.5	41.3	43.0	45.0	48.7	52.5	56.2	59.9	61.8	63.7	67.4	71.7
1,700	10.5	14.0	17.5	21.0	24.5	28.0	32.0	35.9	39.9	43.8	45.7	47.8	51.7	55.7	59.8	63.7	65.6	67.7	71.6	76.2
1,800	11.1	14.8	18.5	22.2	25.9	29.7	33.8	38.0	42.2	46.4	48.4	50.7	54.8	59.0	63.3	67.4	69.5	71.7	75.8	80.7
1,900	11.7	15.6	19.5	23.5	27.4	31.3	35.7	40.1	44.6	49.0	51.0	53.5	57.8	62.3	66.8	71.2	73.3	75.7	80.0	85.2
2,000	12.3	16.5	20.6	24.7	28.8	33.0	37.6	42.2	46.9	51.6	53.7	56.3	60.9	65.6	70.3	74.9	77.2	79.6	84.2	89.7

Estimated project time It only takes 5 minutes to blow one bag of AttiCat® Insulation! Simply multiply the number of bags you need by 5.

straight-forward instructions on how to use this innovative system. You're one step closer to reducing your heating and cooling costs!

TOOLS REQUIRED

Keep yourself clean with a few inexpensive pieces of protective gear:

Face masks are recommended while insulating. Use a properly fitted NIOSH or MSHA-approved disposable dust respirator, such as the 3M Model 8210 (Model 8271, for high-humidity environments) or equivalent.

Eye protection, gloves, pants and a long-sleeved shirt while insulating helps minimize contact with the material and makes for easy cleanup and comfort.





FOR AN EASY PROCESS!

Though a one-person operation is possible, the process is generally easier and faster with two people: one operating the machine at the source and another applying AttiCat® Insulation in the attic. This saves hassle and potentially multiple trips up and down a ladder.

SET-UP OF THE MACHINE

1. ASSEMBLE MACHINE. RUN HOSE TO ATTIC.
2. CUT BAGS IN HALF.



USE OF THE MACHINE

3. PUSH HALF BAG INTO MACHINE.
4. REMOVE PACKAGING.



USE IN THE ATTIC

5. PUSH REMOTE "START" BUTTON TO START MACHINE.
6. BLOW INSULATION TO DESIRED DEPTH.

